


This document explains how to update the TD-01 Portable if it uses firmware version 1.07 or later

Checking the firmware version

Before starting a firmware update, check the firmware version of the TD-01 that you are using.

- 1 Turn the TD-01 Portable on.**
- 2 Press the MENU button to open the Function Menu.**
- 3 Press and hold the ◀ and ▶ buttons.**



Press the ESC button to return to the Function Menu.

Preparing to update the firmware

TdDataPicker must be installed in order to update the firmware. You can download TdDataPicker from the TEAC web site (<https://loadcell.jp/en/products/td-01.html>).

Firmware update procedures

Precautions before updating


- If the TD-01 Portable firmware version is earlier than 1.07, update to version 1.07 first. To do this, follow the procedures included with the 1.07 update file.
- During the firmware update, do not disconnect the USB cable connecting the TD-01 Portable and the computer.
- Only connect one TD-01 Portable to the computer when updating firmware. Firmware cannot be updated when multiple TD-01 Portable units are connected.
- During the firmware update, do not operate the unit.
- During the firmware update, do not quit TdUpdater.
- Updating the firmware could result in the initialization of recorded indicator values, graph data and setting values. As necessary, save indicator values and graph data, and make notes of calibration values and other important settings.

Update procedures


1 Download the update file and decompress it.

Download the latest version of the firmware from the TEAC website (<https://loadcell.jp/en/products/td-01.html>). If the downloaded file is in ZIP format or another compressed file type, decompress it.

2 Click the Windows start button and select TEAC > TD-01 > TdUpdater to launch TdUpdater.




3 Use the included micro USB cable to connect the TD-01 Portable to the computer.




When the computer recognizes the TD-01 Portable, its current firmware version will be shown at the bottom left of the screen.

- 4 Click the File button, and open the update file (extension tcf).**



The firmware version that will be used after the update will appear.

- 5 Click the Start button to start the firmware update.**



The firmware update takes about 10 minutes.
The following explanation will appear after the firmware update completes.
Turn the TD-01 Portable off and on again.

